




Packed cell volume


2 stage

Msc . Ghufraan mershoud

Introduction



A decrease in the number or size of red cells also decreases the amount of space they occupy, resulting in a lower PCV.



An increase in the number or size of red cells increases the amount of space they occupy, resulting in a higher PCV.



Measurement of packed cell volume (PCV) is the **most accurate** and **simplest of all tests** in clinical hematology for detecting the presence and degree of anemia or polycythemia. In comparison, **hemoglobin** estimation is **less accurate**, and **RBCs** count is **far less accurate**.

Purposes of PCV Experiment

1

To know : what is PCV, methods for determination PCV value, and clinical importance of PCV.

2


To determine the volume or the amount of RBCs in 100 *ml* of blood.

3

To assess whether there is a sufficient number of circulating RBCs to transport the required amount of oxygen throughout the body.

Principle of PCV

- *Hematocrit* is derived from Greek words ‘Haima’ meaning “blood” , ‘krites’ meaning “to separate”. Together “*Hematocrit*” means ‘*to separate blood*’ where blood cells and plasma are separated by centrifugation.
- When a known volume of blood is centrifuged, the *cells* being heavier, settle down leaving a clear column of *plasma* above.



Methods

Microhematocrit Method

- Requires less blood and less time to get the value of PCV (commonly used). **It is the method that we are going to use in today lab.**

Macrohematocrit Method

- Also known as a Wintrobe method.
- Time consuming, requires large amount of blood, and has a higher degree of plasma trapping.

Automated Method


- Automated hematology Analyzer.

Materials and Instruments


1. Microhematocrit tube (capillary tube) which is 75 mm in length and 1 mm in diameter . It contains heparin and shows a red ring at one end of the tube.
2. Microhematocrit centrifuge device.
3. Plastic seal to seal one end of the capillary tube.
4. Microhematocrit reader.
5. Lancet, Alcohol 70%, and Cotton.



Microhematocrit tube



Microhematocrit reader



Microhematocrit centrifuge


Procedure and Observations

- Clean your finger with 70% alcohol and let it dry.
- Blood is drawn into the tube by capillary phenomenon. By holding the tube in a horizontal manner and allow 2/3 to 3/4 of the tube to be filled with blood.
- Seal the dry end of the tube by plastic seal.
- The sealed tube then is placed in the radial grooves of the Microhematocrit centrifuge for 5 min at 11000 R.P. m.
- Balance the tubes in the centrifuge with the clay ends facing the outside away from the center(place the tubes opposite each other in the centrifuge). Looking at a centrifuged hematocrit tube, you will see three distinct layers:
 - ***A tall upper layer of clear plasma*** - slightly yellow-colored. It should not be pink or red which would indicate hemolysis of red cells in the sample or within the body in hemolytic diseases.
 - ***A greyish-white (buffy layer)*** thin layer (about 1 mm) in thickness consisting of platelets and WBCs.
 - ***A tall bottom layer of RBCs*** which have been closely packed together.
- Using the hematocrit reader (ruler), read the PCV (Htc) value.




Reading PCV Value

- The capillary tube should be parallel to graduation and lower level of RBCs on zero line of the scale and the upper level of the scale and the upper level of the clear plasma on 100 % line). Do not include the buffy coat (WBCs and platelets) when reading PCV value.




Procedure of PCV experiment




Reading of PCV value


Sources of Errors




- Improper sealing of the capillary tube.




- Time and speed of centrifugation.



- The buffy coat of the specimen should not be included in the PCV reading, because its inclusion would falsely elevate the result.



- A decrease or increase in the readings may be seen if the microhematocrit reader is not used properly.



- The microhematocrit centrifuge should never be forced to stop by applying pressure to the metal cover plate. This will cause the RBCs layer to “sling” forward and results in a falsely elevated value.

14 of 17 Some Factors that affect Hct (PCV)

- 1 Abnormalities of RBCs morphology will affect Hct.
- 2 Raised values of WBC will alter the Hct.
- 3 People from high altitude have increased Hct.
- 4 Chloramphenicol and Penicillin decrease the value.
- 5 Pregnant women have low values due to hemodilution.
- 6 Dehydration and hemodilution will affect the Hct.
- 7 After the hemorrhage values are not reliable.

Clinical Implications

PCV increases in polycythemia and this could be either:

Physiological

- High Altitude and extreme physical exercise or excitement.

Pathological

- Polycythemia Vera, Dehydration leading to Hemoconcentration e.g. diarrhea, burns, and vomiting, Congenital heart failure, and Severe chronic obstructive pulmonary disease (COPD).

Clinical Implications

PCV decreases in :

- ✓ Anemia.
- ✓ Hemoglobinopathies.
- ✓ Cirrhosis.
- ✓ Hemorrhage.
- ✓ Bone marrow failure
- ✓ Renal diseases.
- ✓ Normal pregnancy.
- ✓ Autoimmune diseases.
- ✓ Malignancies like lymphoma, leukemia, multiple myeloma, and Hodgkin's diseases.

Advantages Versus Disadvantages of Microhematocrit Method

Advantages	Disadvantages
<ul style="list-style-type: none">✓ Small sample volume✓ Relatively fast analysis✓ Hemolysis detected when result is read✓ No dilution needed	<ul style="list-style-type: none">✓ Careful preparation required (sealing of capillaries, etc)✓ Leakage of sealing gives falsely low results (more RBCs will be lost than plasma).✓ In blood with abnormally sized or shaped RBCs, more plasma will be trapped, causing a higher positive bias of Hct.✓ Clots will lead to false packing of the cells, giving falsely high Hct.

